

Supermarktkasse

Cash register



Aufbauanleitung
Assembly instructions

DE: Bitte lesen Sie vor Gebrauch sorgfältig die Bedienungsanleitung.


EN: Please read the instruction manual carefully before use.



myToys

Bauteile

Components



1 x A

B




2 x B

C



1 x C

D



1 x D

E



2 x E

F



8 x F


G



40 x G

Aufbau

Assembly



DE: Achtung! Nicht für Kinder unter 36 Monaten geeignet. Erstickungsgefahr aufgrund verschluckbarer Kleinteile. Prüfen Sie den Zustand des Artikels, bevor Ihr Kind damit spielt. Im Fall von Beschädigungen entfernen Sie den Artikel oder die betroffenen Komponenten aus der Reichweite Ihres Kindes. Bewahren Sie die Verpackung für Kommunikationszwecke auf. Entfernen Sie alle Verpackungselemente vor Gebrauch des Artikels.

EN: Warning! Not suitable for children under 36 months. Choking hazard due to small parts. Check the condition of the item before your child plays with it. In case of any damage, remove the item or the affected components from your child's reach. Keep the packaging for any possible future correspondence. Remove all packaging elements before using the article.

Hergestellt für/Manufactured for:
myToys.de GmbH
Potsdamer Straße 192
10783 Berlin
Germany

Artikelnummer: 11578692



The myToys logo, featuring the word 'myToys' in a bold, rounded, black-outlined font.