


HolzKugelbahn

Wooden marble run


Aufbauanleitung
Assembly instructions

myToys

Bauteile Components



1 x A




1 x B




1 x C




1 x D




1 x E




1 x F



2 x F-1




2 x G




1 x H

lang
long




1 x I

lang
long




1 x J

mittellang
middle




1 x K

mittellang
middle




1 x L

kurz
short




1 x M

kurz
short




2 x N

grün
green



2 x O

gelb
yellow



1 x P

rot
red



2 x Q



2 x S



2 x R



2 x T



8 x a




38 x b

Zubehör Accessories



1 x









1 x



4 x

Aufbau Assembly



DE

Achtung! Bitte lassen Sie Ihr Kind beim Spielen mit diesem Spielzeug nicht unbeaufsichtigt. Montage nur durch Erwachsene. Schrauben können sich bei längerem Gebrauch lösen. Bitte kontrollieren Sie die Schrauben regelmäßig. Bitte bewahren Sie die Verpackung für Kommunikationszwecke auf. Bitte entfernen Sie alle Verpackungselemente, bevor Kinder damit spielen.

EN

Warning! Please do not leave your child unattended while playing with this toy. Assembly by adults only. Screws may loosen over time, please inspect all screws periodically. Keep the packaging for any possible future correspondence. All clips, binders, rubber bands, plastic bags and other packaging material are not part of the toy. Please remove them before giving the toy to your child.

Hergestellt für/Manufactured for:
myToys.de GmbH
Potsdamer Straße 192
10783 Berlin
Germany

Artikelnummer: 4758420
Chargen-Nr.: 201707154758420



The myToys logo features the brand name in a large, rounded, bubbly font with a thick black outline.